

Leather Tiles

Regular Maintenance

Ensure the floor has been waxed and buffed thoroughly depending on the usage. Sweep with a soft broom daily. For spills, blot with a soft, very lightly dampened cloth. Do not rub.

General Recommendations

Sweep daily using a broom with soft bristles, paying particular attention to entrance areas and underneath furniture.

Do not mop, use water, or detergents.

When applied to the floor, leather tiles may lose some color in areas of heavy traffic; furniture will mark the tiles.

For deep scratches and marks, apply directly to the area a good-quality shoe polish in the same color as the floor. Colored polish may be mixed into the wax to revive a lackluster floor.

Clean spills immediately. Liquids and oils left on the floor will be absorbed and permanently stain the floor. Use a clean cloth to absorb the spillage.

A regularly waxed floor will act as a temporary barrier to spills and be more resilient than a floor that has only been waxed on installation. However, over-waxing can create an unnecessary build-up of wax.

Leather Tile Cleaning (floor application)

Clean tiles one to two times annually.

Do not wear shoes during this process.

Sweep entire floor with a soft broom.

Using a professional floor buffing machine, buff the entire floor with an electric buffer and only a natural fiber buffing pad such as horsehair.

Sweep entire floor again with a soft broom.

Wax floor by hand with a cotton cloth in four-to-five foot sections. After each section, buff with the natural fiber buffing pad.

Repeat waxing and buffing until floor is completed.

Optional: For extra shine, put a terry cloth towel under the buffer and go over the area one more time. Wait 24 hours before walking on the floor to allow wax to dry.

Leather Tile Cleaning (wall application)

Dust the leather wall as needed. Wax tiles once annually.

Apply wax by hand using a cotton cloth in four-to-five feet sections.

Use a hand-held buffer and a terry cloth bonnet to buff each section after waxing.

Repeat waxing and buffing only for initial waxing, not maintenance.

Change bonnet to lamb's wool and buff entire wall again.

Notes

The above information is intended solely for the purpose of guidance. The level of care required for individual floors and walls needs to be determined by the customer in consideration with the level of usage involved. No responsibility is assumed for any loss or damage, whether directly or indirectly, as a result of the issuance of the above guidance. Neither is any responsibility assumed for any loss or damage in the event that the above guidelines are not followed. Always follow manufacturer's instructions on any products used.