

Maintenance Code

W/B-Clean with water-based cleanser or diluted household bleach.



Regular Maintenance

Vacuum regularly using the proper attachment to avoid pilling. For non-woven textiles, wipe regularly with damp, clean, soft, white cloth or natural sponge.

For wallcovering products, clean with mild soap, lukewarm water and a natural sponge. Rinse with clean, clear water, and dry with a clean, soft, white cloth.

General Recommendations

Treat stains promptly. The longer a stain remains on the textile, the more difficult it will be to remove. A professional furniture cleaning service is recommended.

Always pre-test any cleaning method in an inconspicuous area.

Several light applications of a cleaning agent are less harmful than a single concentrated application. Repeat stain treatment several times if necessary.

Never use heat to clean textiles. Heat can set stains.

Do not use solvent-based cleaning agents such as lacquer thinners, nail polish remover, or pine oil. These agents may cause discoloration over time.

Do not over saturate the textile or let water pool in seams.

Stain Treatment

Soak up any excess moisture immediately.

For oil and water-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon soft-bristle brush with lukewarm, soapy water. Brush the stain with light, quick strokes. Avoid a scrubbing motion and work from the edge of the stain toward the center.

For tougher oil-based stains, confirm the construction of your textile is bleach cleanable. If so, and additional stain treatment is needed, use a 10% solution of diluted household bleach. Thoroughly rinse with cool, clean water to remove any residue.

For ink stains on ink resistant non-woven textiles, a 91% solution of isopropyl alcohol may also be used. Thoroughly rinse with cool, clean water to remove any residue.

For ink stains and scuff marks on vinyl wallcovering, gently blot the stain with isopropyl (rubbing) alcohol. This treatment will lighten the stain but will not remove it completely.

For solid stains (e.g. mud) allow the stain to dry thoroughly and gently break up any hardened areas. Use a nylon, soft bristle brush to remove all loose particles.

For insoluble stains (e.g. chewing gum, candle wax, etc.), use a plastic bag filled with ice to rub the stain until the substance becomes brittle. Use a clean, dull, flat knife to gently remove the substance. If the stain persists, blot the area with a clean, soft, white cloth or natural sponge and lukewarm soapy water.

For blood and bodily fluid stains, follow the oil-based stain treatment above.

If the stain persists, gently dab a pH-neutral cleanser, upholstery spot cleaner, or an equal mixture of water and enzyme detergent (e.g. laundry detergent) on the stain and let it sit for one minute.

Rinse stain treatment thoroughly with a natural sponge moistened slightly with cool, clean water and completely remove all cleaning solution residue as left over residue can attract soil over time.

Extra care should be taken when cleaning dark colors of woven textiles to avoid creating light marks that can be caused by color transfer.

Avoid excess rubbing in order to prevent discoloration and damage to the face of the material.
Do not saturate the surface.

For woven textiles, allow the textile to dry thoroughly and vacuum before using.

Healthcare Recommendations

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process.

Always pre-test in an inconspicuous area before cleaning. After cleaning, rinse repeatedly with cool, clean water to ensure complete removal of all cleaning solution residue. Left over residue can discolor over time.

For a complete list of approved hospital grade cleansers, contact your sales representative.

Notes

The information above is a guide to help in the maintenance of Maharam textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.

Approved Cleaners

3M

3M C. diff Solution Tablets

3M HB Quat Disinfectant Cleaner RTU

Avmor Ltd

Biomor Cleaner and Deodorizer

EP62 Carpet and Fabric Stain Remover

Biotrol

Birex SE

Clorox Professional Products Compan

Citrace Hopsital Germicide

Clorox Hydrogen Peroxide Disinfectant Wipe

Clorox Hydrogen Peroxide Disinfecting Cleaner

Coastwide Laboratories

Hepastat 256 Wipes

Diversey

Accel Prevention Concentrate

Accel Prevention Wipes

Oxivir Tb RTU

Oxivir Tb Wipes

Virex II 256

Virox 5 Rtu Wipes

Virox Ahp 5 Rtu

Ecolab

Disinfectant 1 Wipe

Neutral Disinfectant Cleaner

Oasis 146 Multi-Quat Sanitizer

OxyCide Daily Disinfectant Cleaner

Qc 31 Neutral Cleaner

GOJO Industries

Purell Food Service Surface Sanitizer

Purell Healthcare Surface Disinfectant

Helix Solutions

Chlor Clean Liquid

Johnson Diversey

Fantastik All Purpose Cleaner

Lysol IC

Lysol IC Foaming Disinfectant Cleaner

Medentech Ltd

PureOne

Purtabs

Medline Industries

Micro-Kill Bleach Cermicidal Bleach Wipes

Metrex Research

CaviWipes

CaviWipes 1

CaviWipes Bleach

CaviWipes XL

Midlab, Inc

Maxim Facility +

PDI

Sani-Cloth Af 3 Germicidal Disposable Wipes

Sani-Cloth HB Germicidal Wipes

Sani Professional Brand Table Turners

Sani Professional Cleaning (+ Degreasing) Multi

Super Sani-Cloth Germicidal Disposable Wipe

Pct Corp.

Hydrolyte

RML Rochester Midland Limited

Proxi Spray and Walk Away

Reckitt Benckiser

Lysol Disinfecting Wipes

Russ Medical Supplies

Fade-Adyne II

Safetec of America

SaniZide Plus Germicidal Solution

SciCan

OPTIM 33TB Wipes

Spartan Chemical Company

Super HDQL 10

Sunshine Makers

Simple Green All Purpose Cleaner

The Clorox Company

Clorox Disinfecting Wipes

Clorox Healthcare Bleach Germicidal Wipes

Clorox Healthcare Ez-Kill Quat Alcohol Cleaner

Triple S

Clorox Healthcare Hydrogen Peroxide Cleaner Dis

Clorox Healthcare Multi-Surface Quat Alcohol Cl

Formula 409 All Purpose Cleaner

Greenworks All-Purpose Cleaner

Various

Perisept # 62 Sporocidal Disinfectant Cleaner

Virox Technologies

1:10 Solution of Diluted Household Bleach

1:4 Solution of Diluted Household Bleach

Vital Solutions

Accel Tb Wipes

Peroxigard Wipes

Virox 5 Concentrate

Vital Oxide

Feature

466343

Stain Test Report

Each stain is cleaned with a water-based cleanser after 1 hour and 24 hours. One stain is left untouched as a comparison control.

After each test site is cleaned and dried, the remnants of the stain are evaluated and rated in accordance with the AATCC Stain Release Evaluation Procedure.

Rating System

- 5 - Complete removal
- 4 - Good, traces of stain remain
- 3 - Moderate, 75% of stain removed
- 2 - Fair, 50% of stain removed
- 1 - Poor, less than 50% of stain removed

Type	Rating	Rating
	1 hr	24 hr
Ballpoint Ink *	3	3
Black Coffee	5	5
Blood	5	5
Chocolate	5	5
Cola	5	5
Iodine	5	5
Ketchup	5	5
Mayonnaise	5	5
Mustard	5	3
Red Lipstick	1	2
Red Wine	4	5
Salad Oil	5	5
Sharpie / Permanent Marker *	4	4
Shoe Polish	1	1
Suntan Lotion	5	5 **
Urine	5	5

* Ink was cleaned using a 91% solution of isopropyl alcohol.

** Slight surface bubbling/ blistering