


Vast

466945

## Maintenance Code

W/S/B-Clean with water-based cleanser; mild, water-free dry cleaning solvent, or diluted household bleach.



## Regular Maintenance

Vacuum regularly using the proper attachment to avoid pilling.

## General Recommendations

Treat stains promptly. The longer a stain remains on the textile, the more difficult it will be to remove. A professional furniture cleaning service is recommended.

Always pre-test any cleaning method in an inconspicuous area.

Several light applications of a cleaning agent are less harmful than a single concentrated application. Repeat stain treatment several times if necessary.

Never use heat to clean textiles. Heat can set stains.

Do not over saturate the textile or let water pool in seams.

## Vast 466945

### Stain Treatment

Soak up any excess moisture immediately.

For water-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon soft-bristle brush with lukewarm, soapy water. Brush the stain with light, quick strokes. Avoid a scrubbing motion and work from the edge of the stain toward the center.

For oil-based stains, use a clean, soft, white cloth, a natural sponge, or a nylon, soft-bristle brush with a water-free dry cleaning solvent. Brush the stain with light, quick strokes. Avoid a scrubbing motion. Work from the edge of the stain toward the center.

For tougher oil-based stains, confirm the construction of your textile is bleach cleanable. If so, and additional stain treatment is needed, use a 10% solution of diluted household bleach. Thoroughly rinse with cool, clean water and completely remove all cleaning residue.

For insoluble stains (e.g. chewing gum, candle wax, etc.), use a plastic bag filled with ice to rub the stain until the substance becomes brittle. Use a clean, dull, flat knife to gently remove the substance. If the stain persists, blot the area with a clean, soft, white cloth or natural sponge and lukewarm soapy water.

If the stain persists, gently dab a pH-neutral cleanser, upholstery spot cleaner, or an equal mixture of water and enzyme detergent (e.g. laundry detergent) on the stain and let it sit for one minute.

Rinse stain treatment thoroughly with a natural sponge moistened slightly with cool, clean water and completely remove all cleaning solution residue as left over residue can attract soil over time.

Extra care should be taken when cleaning dark colors to avoid creating light marks that can be caused by color transfer.

Avoid excess rubbing to prevent discoloration and damage to the face of the material.

Do not saturate the surface.

Allow the textile to dry thoroughly and vacuum before using.

### Healthcare Recommendations

Healthcare facilities should follow safety protocols for biological hazards and/or anti-viral treatments during the cleaning process.

Always pre-test in an inconspicuous area before cleaning. After cleaning, rinse repeatedly with cool, clean water to ensure complete removal of all cleaning solution residue. Left over residue can discolor over time.

For a complete list of approved hospital grade cleansers, contact your sales representative.

### Notes

The information above is a guide to help in the maintenance of bleach cleanable upholstery textiles. Maharam can neither guarantee, nor take responsibility for specific results.

Under no circumstances shall Maharam be liable for any incidental, consequential, or other damage resulting from negligence, misuse, mishandling, or exposure of any chemicals used in connection with maintenance. Information relating to chemicals/cleaning solvents, environmental use, and human exposure should be reviewed with appropriate suppliers. All label instructions on their use and precautions should be followed.

Vast  
466945

## Approved Cleaners

### 3M

3M C. diff Solution Tablets  
3M HB Quat Disinfectant Cleaner Concentrate  
3M HB Quat Disinfectant Cleaner RTU

### Various

1:10 Solution of Diluted Household Bleach

### Any

Isopropyl Alcohol (70%)

### Diversey

Oxivir 1  
Oxivir Five 16 Concentrate  
Oxivir Tb RTU  
Oxivir Tb Wipes  
Virex II 256  
Virex Plus

### Ecolab

A-456 II Disinfectant Cleaner  
OxyCide Daily Disinfectant Cleaner

### Johnson Wax

Virex Tb

### Metrex Research

CaviCide  
CaviWipes Bleach  
CaviWipes XL

### PDI

Sani-Cloth Af 3 Germicidal Disposable Wipes  
Sani-Cloth Bleach Germicidal Disposable Wipe

### Reckitt Benckiser

Lysol Disinfecting Wipes

### The Clorox Company

Formula 409 All Purpose Cleaner

### Triple S

Perisept # 62 Sporicidal Disinfectant Cleaner

### Trust Medical

Defender